

Step2:

1. Place Backrest (#17) onto the Backrest Supports (#10), secure them with four M8x $\frac{5}{8}$ " Hex Bolts (#A21), four Flat Washers (#B3).
2. Place Seat (#16) onto the Seat Bracket (#11), secure using four M8x $\frac{3}{4}$ " Hex Bolts (#A24) and four M8 Flat Washers (#B3).
3. Attach the Curl Pad (#18) to the Curl Pad Stand (#8), secure using two M8x $\frac{3}{4}$ " Hex Bolts (#A24) and two M8 Flat Washers (#B3).

Note: To assemble easily, please don't insert the Curl Pad Stand (#8) in the Leg Lever (#5) first.

STEP2

