




Assembly & Operating Instructions PG750 Magnetic Bike



EXPLORATION DRAWING



DRAWING FOR ASSEMBLY



PARTS LIST AND TOOLS


No.	Description	Q'ty
Α	Computer	1PCS
A-1	Screw	4PCS
В	Handlebar assembly	1SET
B-1	End cap	2PCS
B-2	Pulse sensor	2PCS
B-3	Screw	2PCS
B-4	Pulse cable	1PCS
B-5	Foma grip	1PCS
B-6	End cap for pulse cable	1PCS
С	Computer post	1SET
C-1	Computer cable	1PCS
C-2	Screw	2PCS
D	Mainframe	1SET
D-1	Flat washer	4PCS
D-3	Screw	4PCS
D-4	Computer cable, lower section	1PCS
D-5	Bearing	2PCS
D-6	Screw for RPM sensor	1PCS
D-7	RPM sensor	1SET
D-8	Flat washer	1PCS
D-9	C clip	1PCS
D-10	Right chain cover fornt	1PCS
D-11	Right chain cover	1PCS
D-12	Screw	10PCS
D-13	Crank cap	2PCS
D-14	Right Crank	1PCS
D-15	Right pedal	1PCS
D-16	Left pedal	1PCS
D-17	Lock-tie bolt	2PCS
D-18	Left crank	1PCS
D-19	Screw	5PCS
D-20	Left chain cover fornt	1PCS
D-21	Screw	6PCS
D-22	Left chain cover	1PCS
D-23	Wave washer	1PCS
D-24	Flat washer	10PCS
D-25	Adaptor	1PCS


No.	Description	Q'ty
D-26	DC socket with cable	1PCS
D-27	Idler spring	1PCS
D-28	Bottle holder	1PCS
D-29	Ring	2PCS
Е	Flywheel assembly	1SET
E-1	Nut	5PCS
E-2	Star washer	2PCS
E-3	Bearing	1PCS
E-4	Flat washer	1PCS
E-5	Bearing	
E-6	One-Way bearing set	
E-7	Flywheel 1PCS	
E-8	Flywheel axle 1P0	
E-9	Bearing	1PCS
E-10	Small pully	1PCS
E-11	Bearing	1PCS
F	Idler assembly	1SET
F-1	Wave washer	2PCS
F-2	Idler roller	1PCS
F-3	Hex bolt 1P	
F-4	Flat washer	1PCS
F-5	Flat washer	1PCS
F-6	Nylon nut	1PCS
F-7	Flat washer	1PCS
F-8	Hex bolt	1PCS
G	Shaft assembly	
G-1	Bushing	1PCS
G-2	Drive pully	1PCS
G-3	Shaft	1PCS
G-4	Hex bolt	3PCS
G-5	Belt	1PCS
Н	Front stabilizer	1PCS
H-1	Leveling foot	4PCS
H-2	Foot stopper	4PCS
H-3	Foot	4PCS
H-4	Screw	2PCS
H-5	Roller	2PCS
H-6	Flat washer	2PCS
H-7	Nylon nut	2PCS

No.	Description	Q'ty
I	Rear stabilizer assembly	1PCS
I-1	Rear stabilizer	1PCS
J	Seat post assembly	1PCS
J-1	Sleeve	1PCS
J-2	Knob for seat post	1PCS
J-3	Screw	4PCS
J-4	Seat slider cap, Left	1PCS
J-5	Seat slider cap, Right	1PCS
J-6	Seat knob	1PCS
J-7	Flat washer	1PCS
J-8	Screw set	1PCS
J-9	End cap	2PCS
J-10	Seat post	1PCS
J-11	Saddle	1PCS
K-1	Handlebar clamp	1PCS
K-2	Handlebar clamp cover	1PCS
K-3	Flat washer	2PCS
K-4	Lock washer	2PCS
K-5	Screw	1PCS
K-6	T knob for handlebar	1PCS
K-7	Bushing	1PCS
K-8	Screw	8PCS
L	Gear motor	1SET
L-1	Bolt	1PCS
L-2	Flat washer	2PCS
L-3	Hex bolt	2PCS
L-4	Lock washer	2PCS
L-5	Flat washer	2PCS
L-6	Bushing	2PCS
L-7	I-bolt	1PCS
L-8	Hex nut	2PCS
L-9	C clip	2PCS
L-10	Wave washer	1PCS


ASSEMBLY INSTRUCTIONS

Stage#1







- 1. Put on front stabilizer (H) and rear stabilizer (I) to the mainframe assembly. Be noted: the front stabilizer has transportation wheel. Use Screw (K-8) to fix the stabilizers tightly.
- 2. Fix the right pedal (D-15) and left pedal (D-16) tightly to the right/left crank.



- Connect the upper and lower table together.
 Fix the handlebar post to the main frame with Screws (D-3) and washer (D-1).



- 1. Assemble the handlebar (B) to the bracket on the handlebar post with handlebar clamp (K-1), Cover for metal cover (K-2) flat washer (K-3), washer (K-4) and screw (K-5). Bushing (K-7)
- 2. Fix the T-knob (K-6) to the plastic cover. Adjust the handlebar with your desired angle. Fasten the T-knob. Tight the bottle holder (D-28) to the handlebar post with two screws (C-2).




Fasten the saddle (J-11) to the seat post (J). And fix the seat post to the main frame with seat knob (J-2).



 Connect the pulse cable coming out of the handlebar and the computer cable to the computer (A). Place the computer to the computer mast and fasten with Screws (A-1). Then the assembly is done.

Hardware Kit



INSTRUCTION MANUAL OF SM2703

BUTTON FUNCTION:


MODE/ENTER	In stop mode, the mode is to confirm all exercise data setting, and enter into program.
RESET	In stop mode, press the button back to main menu.
START/STOP	To start or stop exercise.
RECOVERY	To test hear rate recovery status.
UP	To select training mode and adjust function value up.
DOWN	To select training mode and adjust function value down.
TOTAL RESET	To power on the computer again.

DISPLAY EXERCISE DATA:

TIME	Display range 0:00~99:99; Setting range 0:00~99:00
DISTANCE	Display range 0.00~99.99; Setting range 0.00~99.90km
CALORIES	Display range 0~9999; Setting range 0~9990
PULSE	Display range P-30~230; Setting range 0-30~230
WATT	Display range 0~999; Setting range 10~350
SPEED	0.0~99.9km
RPM	0~999

OPERATION PROCEDURE


- 1. Connect power supply and computer will power on with a long beep sound, LCD display all segments (drawing A) for 2 seconds and enter into personal data setting mode (gender, age, height and weight) for U1~U4. (drawing B~C)
- 2. After user data set up, computer will display main menu (drawing D).



3. In main menu, first exercise program MANUAL will flash, user may press UP and DOWN button to select MANUAL →PROGRAM (12 profiles) (drawing E)→PROGRAM→USER

PROGRAM→HRC→WATT.





4. Quick Start and Manual:

Before exercise in Manual mode, user my set up TIME, DISTANCE, CALORIES and PULSE target.

After power on, user may press START/STOP button to start exercise in MANUAL immediately without any setting.

Level can be adjusted during exercise by press UP or DOWN.

5. PROGRAM:

Before exercise in Program mode, user may set up TIME target.

Press UP and DOWN to select Program with 12 profiles and press ENTER/MODE to confirm. Level can be adjusted during exercise by press UP or DOWN.

6. H.R.C.:

Before exercise, computer will ask for user AGE first to calculate TARGET pulse. User may still press UP and DOWN to change target pulse from 30 to 230.

7. USER PROGRAM:

User may press UP, DOWN and then press MODE to create his own profile. (from column 1 to column 20) User may hold on pressing MODE button for 2 seconds to quit profile setting.

8. WATT:

The preset watt value 120 is flashing on screen in WATT setting mode. User may use UP, DOWN button to set target value from 10 to 350. Press MODE button for confirm.

9. RECOVERY:

After exercising for a period of time, keep holding on handgrips and press "RECOVERY" button. All function display will stop except "TIME" starts counting down from 00:60 to 00:00. Screen will display your heart rate recovery status with the F1,F2....to F6. F1 is the best, F6 F6 is the worst. User may keep exercising to improve the heart rate recovery status. (Press the RECOVERY button again to return the main display.)

NOTE:

- 1. This computer require 9V, 500mA adaptor.
- 2. When user stop pedaling for 4 minutes, computer will enter into power save mode, all setting and exercise data will stored until user start exercise again.
- 3. When computer act abnormal, please plug out the adaptor and plug in again.